

Troubleshooting ThinLINE Hydraulic Ratcheting Torque Wrenches 5K and 10K Models

Problem	Possible Solutions
The cylinder does not	The "Quick Disconnects" are not connected properly.
extend or retract.	Check your connections.
The "Quick Disconnects" will not lock, or will not release.	The hydraulic hose is still pressurized. Release the pressure in the hose.
The wrench locks up on	The anti-reverse pawl is jammed.
the bolt.	Release the anti-reverse pawl.

Storage Tips

- When storing the ratchet wrench fully, retract the cylinder.
- Rinse and clean the wrench after every job, then lubricate with light oil film.